endangering the safety of the airplane or the occupants. Each Class D compartment must comply with the following:

- (1) It must have a means to exclude hazardous quantities of smoke, flames, or noxious gases from entering any compartment occupied by the crew or passengers.
- (2) Ventilation and drafts must be controlled within each compartment so that any fire likely to occur in the compartment will not progress beyond safe limits.
- (3) It must be completely lined with fire-resistant material.
- (4) Consideration must be given to the effect of heat within the compartment on adjacent critical parts of the airplane.
- (f) Class E. On airplanes used for the carriage of cargo only, the cabin area may be classified as a Class "E" compartment. Each Class E compartment must comply with the following:
- (1) It must be completely lined with fire-resistant material.
- (2) It must have a separate system of an approved type smoke or fire detector to give warning at the pilot or flight engineer station.
- (3) It must have a means to shut off the ventilating air flow to or within the compartment and the controls for that means must be accessible to the flight crew in the crew compartment.
- (4) It must have a means to exclude hazardous quantities of smoke, flames, or noxious gases from entering the flight crew compartment.
- (5) Required crew emergency exits must be accessible under all cargo loading conditions.

§ 121.223 Proof of compliance with § 121.221.

Compliance with those provisions of §121.221 that refer to compartment accessibility, the entry of hazardous quantities of smoke or extinguishing agent into compartments occupied by the crew or passengers, and the dissipation of the extinguishing agent in Class "C" compartments must be shown by tests in flight. During these tests it must be shown that no inadvertent operation of smoke or fire detectors in other compartments within the airplane would occur as a result of fire

contained in any one compartment, either during the time it is being extinguished, or thereafter, unless the extinguishing system floods those compartments simultaneously.

§121.225 Propeller deicing fluid.

If combustible fluid is used for propeller deicing, the certificate holder must comply with §121.255.

§ 121.227 Pressure cross-feed arrangements.

- (a) Pressure cross-feed lines may not pass through parts of the airplane used for carrying persons or cargo unless—
- (1) There is a means to allow crewmembers to shut off the supply of fuel to these lines; or
- (2) The lines are enclosed in a fuel and fume-proof enclosure that is ventilated and drained to the exterior of the airplane.

However, such an enclosure need not be used if those lines incorporate no fittings on or within the personnel or cargo areas and are suitably routed or protected to prevent accidental damage.

(b) Lines that can be isolated from the rest of the fuel system by valves at each end must incorporate provisions for relieving excessive pressures that may result from exposure of the isolated line to high temperatures.

§ 121.229 Location of fuel tanks.

- (a) Fuel tanks must be located in accordance with §121.255.
- (b) No part of the engine nacelle skin that lies immediately behind a major air outlet from the engine compartment may be used as the wall of an integral tank.
- (c) Fuel tanks must be isolated from personnel compartments by means of fume- and fuel-proof enclosures.

§ 121.231 Fuel system lines and fittings.

- (a) Fuel lines must be installed and supported so as to prevent excessive vibration and so as to be adequate to withstand loads due to fuel pressure and accelerated flight conditions.
- (b) Lines connected to components of the airplanes between which there may be relative motion must incorporate provisions for flexibility.